



10 Dallas Court Hallam, Victoria 3803 ABN 27 106 103 315

www.aggdoors.com.au enquiries@aggdoors.com.au (03) 8789 1385



Genuine TM3

Transmitter Coding

- 1. Press and hold the button of the working transmitter.
- 2. Keep holding the **working** transmitter button. Get the **new** transmitter and position it on by head to head or LED to LED with the **working** transmitter.
- 3. While still holding the **working** transmitter button, press and hold the same button on the **new** transmitter as well.
- 4. The LED on the **new** transmitter should flash twice and stay on.
- 5. Release the button of the **new** transmitter before releasing the **working** transmitter.
- 6. Press the button on the **new** transmitter and it should log on to the decoder. Gate or garage should start to work.







