

**INDUSTRIAL
ROLLER
DOOR REPAIR**



10 Dallas Court Hallam, Victoria
3803 ABN 27 106 103 315
www.aggdoors.com.au
enquiries@aggdoors.com.au
(03) 8789 1385



mHouse TX3

Coding Instruction

1. Unscrew the screw on the side of the motor and slide up the cover.
2. Locate the P1 Button on the motor.
3. Press and hold the P1 button for about 3 seconds or until the red light on the motor illuminates.
4. Press and hold your desired button on your remote for approximately 2 seconds until the light on the motor flashes.
5. Test remote to make sure it has coded successfully.

