Genuine TRG

Programming Your Remote into your Opener

1. Remove the cover off the old remote (if no existing remote, remove the cover off the motor).
2. Remove the cover off the new remote.
3. Copy the 8 dipswitch code located on the circuit board from the old remote to the new remote.
4. Test the remote to make sure the code is correct.
5. Reattach the covers.