

**INDUSTRIAL  
ROLLER  
DOOR REPAIR**



10 Dallas Court Hallam, Victoria  
3803 ABN 27 106 103 315  
[www.aggdoors.com.au](http://www.aggdoors.com.au)  
[enquiries@aggdoors.com.au](mailto:enquiries@aggdoors.com.au)  
(03) 8789 1385



***ECA REMOTES***

## **Coding in Your Remotes to the Opener**

### **Method 1**

1. Take the operational remote control of the unit and stand about 2m' from the receiver. Press and hold both the buttons (III) and (I) simultaneously for 5 seconds (If this does not work, please hold buttons (I) and (II) instead).

2. After releasing the buttons of the original remote control, the LED light in the receiver will turn on.

Indicating that the receiver is ready to learn the new remote control's button.

3. Choose, press and hold the one of the buttons on the NEW remote control for 5 seconds and then

release. The LED light will turn off to indicate that the remote control's button has been learned into the receiver's memory.

- 1.Remove the jumper "Clear" in the receiver and the LED light will turn on.
- 2.Choose, press and release the button on the new remote control, which you would like to operate the receiver, for a period of five second.
- 3.Return the "Clear" jumper to its place.
- 4.Repeat steps 1-4 for teaching more remote controls.

