

**INDUSTRIAL
ROLLER
DOOR REPAIR**



10 Dallas Court Hallam, Victoria
3803 ABN 27 106 103 315
www.aggdoors.com.au
enquiries@aggdoors.com.au
(03) 8789 1385



Genuine TM1

Transmitter Coding

1. Press and hold the button of the **working** transmitter.
2. Keep holding the **working** transmitter button. Get the **new** transmitter and position it on by head to head or LED to LED with the **working** transmitter.
3. While still holding the **working** transmitter button, press and hold the same button on the **new** transmitter as well.
4. The LED on the **new** transmitter should flash twice and stay on.
5. Release the button of the **new** transmitter before releasing the **working** transmitter.
6. Press the button on the **new** transmitter and it should log on to the decoder. Gate or garage should start to work.

