

INDUSTRIAL
ROLLER
DOOR REPAIR



10 Dallas Court Hallam, Victoria
3803 ABN 27 106 103 315
www.aggdoors.com.au
enquiries@aggdoors.com.au
(03) 8789 1385



Programming your Keypad into the Opener

1. Locate the learn button on the opener
2. Press and release the learn button. The LED will light.
3. Enter a 4 digit PIN of your choice
4. Press and hold the Enter button until the light bulb blinks once or 2 clicks are heard.

